



TECHNISCHE  
UNIVERSITÄT  
WIEN  
Vienna University of Technology

VIENNA UNIVERSITY OF TECHNOLOGY

FACULTY OF PHYSICS

LABORATORY III

---

# Laboratory Report

Elasticity Modulus

---

**Authors:**

Raul Wagner

Martin Kronberger

**Group 301**

**Supervisor:**

conducted on:  
18 June 2025

## Contents

1	Elasticity Modulus of Tension Rods .....	2
1.1	Fundamentals .....	2
1.2	Setup .....	2
1.3	Procedure .....	2
1.4	Measurement Values .....	2
1.5	Data Analysis .....	3
2	Bending Beam Analysis .....	3
2.1	Fundamentals .....	3
2.2	Setup .....	3
2.3	Procedure .....	3
2.4	Measurement Values .....	3
2.5	Data Analysis .....	4
	Bibliography .....	5

# 1 Elasticity Modulus of Tension Rods

## 1.1 Fundamentals

The elasticity modulus (Young's modulus)  $E$  describes the relationship between stress and strain in the elastic deformation region. For a tension rod under axial load:

$$E = \frac{\sigma}{\varepsilon} = \frac{\frac{F}{A}}{\Delta \frac{L}{L_0}} \quad (1)$$

where  $F$  is the applied force,  $A$  is the cross-sectional area,  $\Delta L$  is the elongation, and  $L_0$  is the original length. The measurement uses strain gauges with a bridge circuit configuration.

## 1.2 Setup

### Equipment:

- Bridge extension device
- Tension rods (Aluminum, Steel, Brass, Plexiglas)
- Strain gauge measurement system
- Calibrated weights or voltage source
- Digital multimeter

### Material Specifications:

- Aluminum:  $D = 14.85$  mm,  $d = 3.7$  mm
- Steel:  $D = 15$  mm,  $d = 2.2$  mm
- Brass:  $D = 15.8$  mm,  $d = 3$  mm
- Plexiglas:  $D = 15.2$  mm,  $d = 7.7$  mm

**K-factor:**  $k = 2.03 \pm 1\%$  (pre-calibrated)

## 1.3 Procedure

1. Switch the bridge extension device to 1/2 position
2. Connect the first tension rod to the bridge extension
3. Wait 5 minutes for thermal equilibration
4. For each material, perform 4 measurement series:
  - Series with 5V and 2.5V excitation voltage, OR
  - Series with 2 kg and 5 kg loading
5. Take at least 6 measurements per series
6. Record all voltage readings and corresponding loads
7. Repeat for all four materials

## 1.4 Measurement Values

### Data Table Template:

Material	Load (kg)	Voltage (V)	Strain ( $\mu\varepsilon$ )	Stress (MPa)	Trial
Al					
Steel					
Brass					
Plexiglas					

## 1.5 Data Analysis

1. Calculate cross-sectional area:  $A = \frac{\pi}{4}(D^2 - d^2)$
2. Calculate stress:  $\sigma = \frac{F}{A}$
3. Calculate strain from voltage readings:  $\varepsilon = \frac{U}{k \cdot U_{\text{bridge}}}$
4. Plot stress vs. strain for each material
5. Determine  $E$  from the slope of the linear region
6. Perform error propagation analysis considering individual measurement uncertainties
7. Compare experimental values with literature values

## 2 Bending Beam Analysis

### 2.1 Fundamentals

For a cantilever beam under point load, the deflection  $w$  is related to the applied force  $F$  by:

$$w = \frac{FL^3}{3EI} \quad (2)$$

where  $L$  is the beam length,  $E$  is the elasticity modulus, and  $I$  is the second moment of area. The relationship between bending moment and curvature is:

$$M = EI\kappa \quad (3)$$

### 2.2 Setup

#### Equipment:

- Cantilever beam setup
- Displacement measurement system (dial gauge or LVDT)
- Calibrated weights
- Ruler for length measurements
- Caliper for cross-section measurements

#### Beam Configuration:

- Length  $L$  to be measured
- Cross-section dimensions to be determined
- Support conditions: fixed-free (cantilever)

### 2.3 Procedure

1. Set up the cantilever beam with proper clamping
2. Ensure the beam is horizontal using a level
3. Position the displacement measurement device at the free end
4. Apply loads incrementally (suggested: 0.5, 1.0, 1.5, 2.0 kg)
5. Wait for stabilization between each load increment
6. Record deflection for each load
7. Repeat measurements 3 times for statistical analysis
8. Unload and check for permanent deformation

### 2.4 Measurement Values

#### Data Collection:

Load $F$ (N)	Deflection $w$ (mm)	Trial 1	Trial 2	Trial 3
0	0			

## Laboratory Work III - Elasticity Modulus

4.9				
9.8				
14.7				
19.6				

### Beam Geometry:

- Length  $L =$  mm
- Width  $b =$  mm
- Height  $h =$  mm
- Second moment of area  $I = \frac{bh^3}{12} = \text{mm}^4$

### 2.5 Data Analysis

1. Plot load  $F$  vs. deflection  $w$
2. Determine the slope  $k = \frac{\Delta F}{\Delta w}$
3. Calculate theoretical deflection:  $w_{\text{theory}} = \frac{FL^3}{3EI}$
4. Compare experimental slope with theoretical prediction
5. Calculate experimental elasticity modulus:  $E_{\text{exp}} = \frac{FL^3}{3Iw}$
6. Analyze linearity and determine measurement uncertainty
7. Calculate percentage error compared to known material properties
8. Discuss sources of experimental error (beam self-weight, clamping effects, measurement precision)

### Error Analysis:

- Systematic errors: calibration, geometric measurements
- Random errors: measurement repeatability, environmental factors
- Propagation of uncertainties through calculations

**Expected Results:** Compare experimental values with typical elasticity moduli for common materials (Steel: 200 GPa, Aluminum: 70 GPa).

**List of Tables**

**List of Figures**

**Bibliography**